



In-Ceiling Speaker Installation Instructions:

- Place the cardboard cutout template on the ceiling where you want the speaker to be mounted.
- Draw around the template and cutout the speaker mounting hole.
- Run quality speaker wire (12-16 gauge) to that location.
- Connect the speaker wire to the binding posts and insert the speaker into the speaker mounting hole.
- There are 4 screws around the perimeter of the face of the speaker. These screws connect to 'wings' in the rear of the speaker which will swing out and clamp the speaker to the wall or ceiling as they are tightened. Secure the speaker to the ceiling by tightening these screws until the speaker is securely mounted.
- Attach grille.

