



Congratulations on your purchase of a Pinnacle K DVC 600 or K DVC 800 in-ceiling speaker. This speaker is designed for use in locations where a pair of in-ceiling speakers would be inappropriate or problematic. The dual voice coil woofer handles both the left & right channel bass functions while the dual pivoting tweeters allow the high frequencies to be directed towards the listening area for the best response.

Inwall & Ceiling Speaker Installation Instructions:

- Take the cardboard cutout template that comes with the speakers and place it where you want the speaker to be mounted. Draw around the template and cutout the speaker mounting hole.
- Run 2 pairs (Left & Right channel) of quality speaker wire (12-16 gauge) to that location.
- Carefully pry off the grill from the speaker either using a small screwdriver at the edge of the grill or with a small awl catching the grill by one of its holes.
- Connect one pair of speaker wire to either set of binding posts and the other pair of speaker wire to the second set of binding posts. Be sure to observe proper polarity (+ to +, - to -).
- Insert the speaker into the hole.
- There are 4 screws around the perimeter of the face of the speaker. These screws connect to clamps in the rear of the speaker which will swing out and hold the speaker to the ceiling as they are tightened. Secure the speaker to the ceiling by tightening these screws until the speaker is securely mounted.
- Reattach grill.

That's It! Enjoy!

